


How to use CURVE-16W IES Files

Default Wall Mount Position:

CURVE-16W-L: Orient = 0° , Tilt = 0°

CURVE-16W-R: Orient = 0° , Tilt = 0°



Wall Mount Position with 20° Tilt:

CURVE-16W-L: Orient = 0° , Tilt = 20°

CURVE-16W-R: Orient = 0° , Tilt = -20°

